



Mobile and Barcode

The Proteus Mobile module transfers PM/DM work orders from Proteus to devices running Windows Mobile® 5.0. This allows users to:

- Receive work orders on a mobile device
- Create new work orders on the job
- Update labor hours and parts quantities used
- Update existing PM/DM work orders
- View history


The Mobile module frees maintenance staff from paperwork, giving them more time to do the work they are hired for.

The Barcode module makes it easy to label and track equipment, inventory, employees and

work orders. Users can barcode work orders to collect information on PM and DM work orders in the field.

Use the Barcode and Mobile modules together to:

- Update equipment runtime
- Adjust physical inventory
- Update tasks, parts & labor on PM and DM work orders
- Scan equipment to select work orders
- Reduce entry errors



ProTeus 9.7.0 - [PM Master - AHU-002]

Assets Maintenance Personnel Purchasing Other Reports Windows Help

Quick List PM Master Equipment Date Schedule Tasks Parts Labor Tools W/O Desc. User Fields Attachments Mobile

Search Char. Query

Job No.	Equipment No.
AHU-002	AHU002
FLT-001	FLT001
GEN-001	MSC001
PRS-001	PRS001
VEH-001	VEH100

Job No. AHU-002 Equipment No. AHU002

Priority HIGH Equipment Name AIR HANDLING UNIT

Location MAIN PLANT

Procedure Description INSPECTION OF AIR HANDLING UNIT

Send E-mail

Auto Print Print Attachments Auto Activate

Part No. FLT001 Employee No. 10012003

Part Name AIR FILTER Employee Name DONALD BARTON

Qty Allocated 1 Est. Hours 0.3

Daily Monthly Semi-Annual

Weekly Quarterly Annual

